

Enduroplank™

Installation



Enduroplank™ is similar to timber to install; however, there are some key points which will reduce your installation time and result in a better finished product.

To fully understand the properties and capabilities of the product, visit the *Enduroplank™* page of our website.

Installing

Place **two fixings** through the thickest part of the plank to secure to the central joist. Where there is an even number of joists, secure the two most central joists in the same way.

Place **one fixing** through the centre of each plank, for as many joists as support the plank.



Drilling

Enduroplank™ can be drilled with the same tools and accessories as timber.

Fixing points should be pre-drilled with an 8 mm hole and countersunk.

Recommended fasteners

Composite fibre

75 mm bugle batten 14 gauge screws

Timber/plastic

100 mm bugle batten 14 gauge screws

Steel

Coach bolt as per traditional methods

Extreme Coil Auto Feed from Powers®

Ideal for large, repetitive projects. See the website for more information.

Replas can provide all of the above accessories and more to make your job as efficient and safe as possible.

Spanning

Detailed information regarding spanning is available on the *Enduroplank™ Specifications* page of our website.


Pedestrian/cycle traffic— a maximum span distance of 600 mm between joists is recommended.

Light vehicles— a maximum span distance of 400 mm between joists is recommended.

It is not recommended that Enduroplank™ be laid longitudinally, due to expansion and contraction issues.



Drill and countersink



Bugle Batten screws

Cutting Enduroplank™

To create a cleaner cut and reduce the risk of over-heating when cutting Enduroplank™, Replas recommends a thin kerf blade with anti-kick, and as few teeth as possible.



An 18 or 20 toothed blade is recommended for use with a drop saw.

Drop saw



A 4 or 6 toothed blade is recommended for use with a circular saw.

Circular saw

Curved boardwalk

Enduroplank™ may be tapered to create curves. The *Enduroplank™* page of our website contains more information, or visit the *News & Media* tab to view our instructional videos. Pre-cut tapered boards are available.

116.5 mm  195 mm

Tapered Enduroplank™

Kick Rails & fascia coverings

Recycled-plastic profiles can be used for kick rails or fascia coverings. They are tough, aesthetically pleasing and provide the perfect solution to complete your structure. Profiles may also be used to create water drainage scuppers below the kick rail.

A 10 mm gap between lengths of kick rail will allow for expansion and contraction.



Fascia coverings



Kick rail & scuppers

Packing accessories

Enduroplank™ should be spaced at 5 mm intervals. It is important to continuously monitor and measure to ensure a consistent outcome; smaller or larger packers may be required in some circumstances.

Packers are available from Replas.

More information

Our website www.replas.com.au contains a range of information including instructional videos.

Documents

- Brochure
- Curved Enduroplank™ Specifications
- Enduroplank™ Pattern Effect
- Enduroplank™ Installation
- Sand Coating information
- Faster Installation- Saving time and money

External testing

- Enduroplank™ Slip Resistance Test
- Enduroplank™ Loading Test 800 mm span
- Enduroplank™ Sand Coating Slip Report
- Enduroplank™ Load testing AS 3962

Videos - Instructional

- Cutting and drilling our plastic
- Curved recycled plastic planking

Videos - Case studies

- Twelve Apostles, VIC - Footbridge
- Cattane Wetlands, QLD - Boardwalk
- Fogg Dam Reserve, NT - Boardwalk
- MaMu National Park, QLD - Boardwalk
- St Kilda, VIC - Boardwalk
- South West Rocks, NSW - Bridge
- Mt Henry, WA- Jetty
- Ferntree Gully, VIC - Staircase